

- **WAAS Differential Correction Enabled on GPS**
 - **HDS Gen1&2: Press MENU twice, select SYSTEM, select SATELLITES, select CONFIGURE, enable WAAS**
 - **HDS Gen2 Touch: Press the Pages button, select SETTINGS, select SYSTEM, select SATELLITES, select CONFIGURE, enable WAAS**